
Meridian Administration Tools

Maintenance Windows

User Guide

Document Number: P0843839
Document Release: Standard 5.7
Date: October 1997

© 1996, 1997
All rights reserved

Printed in the United States of America

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules.

MAT and Meridian 1 are trademarks of Northern Telecom.

Contents

Maintenance Windows	1
Launching a Maintenance Windows application	2
Maintenance Windows applications	4
Full documentation in on-line help	5
Performing a maintenance task on an item	7
Menu Commands	9
Getting help on an error message	9
Getting around in the window	10
Printing	11
Supported Systems	12
Feature Limitations	13
 Core CPU window	 15
Launching Core CPU	15
Core CPU window column descriptions	16
Supported Commands	17
 I/O Ports window	 19
Launching I/O Ports	19
I/O Ports column definitions	20
Supported Commands	23
 Network Groups window	 25
Launching Network Groups	25
Network Groups column definitions	26
Supported Commands	27
 Network Loops window	 29
Launching Network Loops	29

Network Loops column descriptions	30
Supported Commands	31
PE Shelves window	33
Launching PE Shelves	33
PE Shelves column definitions	34
Supported Commands	34
PE Cards window	35
Launching PE Cards	35
PE Cards column definitions	36
Supported Commands	37
PE Units window	39
Launching PE Units	39
PE Units column definitions	42
Supported Commands	43
B and D-channels window	47
Launching B and D-channels	47
B and D-channels column definitions	48
Supported Commands	48